

1. Extract the driver files from the downloaded .zip file
2. Locate the file name “**setup.exe**” in the folder “**TU3-ETG_Win10 Setup**”. Double click on the file to run the installation process.

1045.mst	3/10/2020 1:23 PM	MST File	88 KB
1046.mst	3/10/2020 1:23 PM	MST File	88 KB
1048.mst	3/10/2020 1:23 PM	MST File	84 KB
1049.mst	3/10/2020 1:23 PM	MST File	84 KB
1050.mst	3/10/2020 1:23 PM	MST File	84 KB
1051.mst	3/10/2020 1:23 PM	MST File	84 KB
1053.mst	3/10/2020 1:23 PM	MST File	80 KB
1054.mst	3/10/2020 1:23 PM	MST File	80 KB
1055.mst	3/10/2020 1:23 PM	MST File	84 KB
1057.mst	3/10/2020 1:23 PM	MST File	84 KB
1060.mst	3/10/2020 1:23 PM	MST File	84 KB
1069.mst	3/10/2020 1:23 PM	MST File	84 KB
2052.mst	3/10/2020 1:23 PM	MST File	64 KB
2070.mst	3/10/2020 1:23 PM	MST File	88 KB
3084.mst	3/10/2020 1:23 PM	MST File	92 KB
3098.mst	3/10/2020 1:23 PM	MST File	80 KB
Autorun.inf	3/10/2020 1:23 PM	Setup Information	1 KB
instmsiw.exe	11/28/2004 9:53 AM	Application	1,780 KB
ISSetup.dll	3/10/2020 1:23 PM	Application exten...	5,181 KB
setup.exe	3/10/2020 1:24 PM	Application	971 KB
Setup.ini	3/10/2020 1:23 PM	Configuration sett...	3 KB
Silent_install.bat	6/3/2009 4:45 PM	Windows Batch File	1 KB
TUC-ETG_TU3-ETG Windows 10 Drivers.msi	3/10/2020 1:23 PM	Windows Installer ...	321 KB

3. Follow the instructions to install the driver and click **Finish** when the installation is complete.